

Wall Switches & Remote Controls

	Controls	Brand ^p	Wall or Remote	IPI or SP†	On/Off	Battery Strength Indicator	Automatic Battery Backup	Fan Speed	Flame Control	Flame Modulation	Pilot Activation	AUX Function	Temp Readout	Thermostat Mode	Timer Mode	7-Day Programmable
IntelliFire Plus Wireless Controls	IntelliFire Plus RC300	HTL, HNG, QDF	Remote	IPI	●	●	●	●	5 STEP	●	●	● (three)‡	●	●	●	
	IntelliFire Plus RC200	HTL, HNG, QDF	Remote	IPI	●	●	●	●	5 STEP		●					
	IntelliFire Plus RC100	HTL, HNG, QDF	Wall	IPI	●	●	●									
Wireless Controls	TotalRemote RCT-MLT	HTL, HNG, QDF	Remote	Both	●			●	HIGH/LOW				●	●	●	
	SmartRemote-Battery SMART-BATT, 841-970	HTL, HNG, QDF	Remote	Both	●								●	●	●	
	SmartRemote-Hardwired SMART-STATT, 841-0960	HTL, HNG, QDF	Remote	Both	●								●	●	●	
Wired Wall Controls	TotalSwitch WSK-MLT	HTL, HNG, QDF	Wall	Both	●			●	HIGH/LOW		●	● (one)	●	●		
	IntelliSwitch®200 WSK200	HTL, HNG, QDF	Wall	IPI	●	●	●	●			●					
	EasySwitch WSK-21 & WSK-21-W	HTL HNG	Wall	Both	●											
	Programmable Thermostat 811-0520	QDF	Wall	Both									●	●		●
	Thermostat 812-3760	QDF	Wall	Both									●	●		

Feature Glossary

On/Off: Turns the flames on and off.

Battery Strength Indicator: IntelliSwitch200 – red led blinks to alert homeowner that new batteries are needed; solid- on indicator signifies that the hearth system is operating on battery power. IntelliFire Plus RC100 & 200 – red led blinks when button is pressed. Lack of red led light signifies that the batteries need changed. IntelliFire Plus RC300 - Displays a battery strength icon.

Automatic Battery Backup: Senses power failure and automatically switches the unit to battery operation, keeping you and your family warm.

Fan Speed: Adjusts the speed of the fan, pushing heat into the room.

Flame: Adjusts the height of the flames, affecting ambiance and heat output.

Pilot Activation: Changes the pilot from 'as-needed' (activated only when the fireplace is turned on) to 'constant-on' (seasonal pilot remains on to improve performance during the coldest times of the year).

AUX Function: Controls assigned auxiliary functions, such as accent lighting or electric embers.

Temp Readout: Communicates room temperature.

Thermostat Mode: Maintains the specified room temperature by adjusting the hearth system, much like a furnace thermostat.

Timer Mode: Shuts flames off automatically at a pre-set time.

7-Day Programmable: Control room temperature settings on a weekly cycle.



The IntelliFire™ Plus Ignition System (IPI Plus) is an advanced intermittent pilot ignition system with memory settings and

a programmable wireless control. IPI Plus constantly monitors ignition, ensures safe functioning and conserves up to \$10/month in energy costs.

To learn more about IntelliFire Technology, scan the code to the right with your smartphone, or visit fireplaces.com.



† IPI = Intermittent Pilot Ignition
SP = Standing Pilot

‡ Fan speed is one of three auxiliary functions

^p HTL = Heatilator
HNG = Heat & Glo
QDF = Quadra-Fire

HEARTH & HOME
technologies
The Hearth Experts™

Lakeville, MN
(888) 427-3973 (952) 985-6000
Web: fireplaces.com
HHT-1003U-0713

Controls FOR GAS FIREPLACES



heatilator

HEAT & GLO

QUADRA-FIRE

Heat at your fingertips - The warmth of home at your control.



Hearth & Home controls are uniquely designed to conveniently start your fire with a simple, easy click. Select the control that best meets your needs and your hearth features.

A sleek wall switch stays in one convenient location while a remote control goes where you go. Wireless controls bring added convenience of handy remote access, as well as a wall docking station.

All controls are UL listed and approved for use with Heatilator, Heat & Glo or Quadra-Fire products.

INTELLIFIRE™ PLUS WIRELESS CONTROLS

IntelliFire Plus RC300 is specifically designed for use with our new IntelliFire Plus ignition system. It is easy-to-use, stylish and ergonomic in design. Features an LCD screen, intuitive menus and large buttons. This wireless control allows flexibility for wall placement, or use as a remote only.

Models: RC300

Features: On/Off, Auto Battery Backup, Pilot Activation, 5 Step Flame Height, Fan Speed (auxiliary 1), two additional Auxiliary Functions, Room Temperature Readout, Thermostat Mode, Timer, Child Lock, Wall Docking Station



IntelliFire Plus RC200 is specifically designed for use with our new IntelliFire Plus ignition system. It is easy-to-use, stylish and ergonomic in design. As a wireless control, it has the flexibility for wall placement, or use as a remote only.

Models: RC200

Features: On/Off, Auto Battery Backup, Pilot Activation, 5 Step Flame Height, Fan Speed, Child Lock, Wall Docking Station



IntelliFire Plus RC100 Designed specially for fireplaces with IntelliFire Plus, our state-of-the-art intermittent pilot ignition system.

Models: RC100

Features: On/Off



WIRELESS CONTROLS

TotalRemote This remote control effortlessly manages heat output and comfort level. For use with Heatilator, Heat & Glo and Quadra-Fire.

Models: RCT-MLT, 841-0980

Features: Hardwired Receiver, On/Off, Timer Mode, Thermostat Mode, Room Temperature Readout, Flame High/Low, Fan Speed



SmartRemote For homeowners who want an added level of function and convenience in a remote control for fireplaces, stoves, inserts and gas logs. For use with Heatilator, Heat & Glo and Quadra-Fire.

Models: 841-970, 841-0960, SMART-BATT, SMART-STAT

Features: Battery-Powered or Hardwired Receiver, On/Off, Timer Mode, Thermostat Mode, Room Temperature Readout



WIRED WALL CONTROLS

TotalSwitch Command of both comfort and ambiance from one location. For use with Heatilator, Heat & Glo and Quadra-Fire.

Model: WSK-MLT

Features: On/Off, Thermostat Mode, Room Temperature Readout, Auxiliary Function, Flame High/Low, Pilot Activation, Fan Speed



Programmable Thermostat Control your hearth system based on your weekly schedule. UL listed for use with

Quadra-Fire.

Model: 811-0520

Features: On/Off, 7-Day Programmable, Thermostat Mode, Room Temperature Readout



IntelliSwitch200 Designed specially for Heatilator, Heat & Glo and Quadra-Fire fireplaces with IntelliFire, our UL listed state-of-the-art intermittent pilot ignition system.

Models: WSK200

Features: On/Off, Auto Battery Backup, Battery Strength Indicator, Pilot Activation, Fan Speed



Thermostat Simple temperature-based control of your hearth system. UL listed for use with Quadra-Fire.

Model: 812-3760

Features: On/Off, Room Temperature Readout



Easy Switch Controls the most basic functions of the fireplace—on/off—in the easiest way possible.

Models: WSK-21, WSK-21-W

Features: On/Off

